




- ⓃⓄ Monterings- og bruksanvisning
- Ⓢⓔ Installations- och bruksanvisning
- ⓖⓑ Installation and user manual
- ⓕⓖ Asennus ja käyttöohje
- ⓓⓔ Installations und Benutzerhandbuch
- ⓕⓗ Manuel d'installation et d'utilisation
- ⓓⓀ Installations- og brugervejledning




Me Bench - Black Steel Front

FIG 1

Me Bench - Black Steel Front = mm / air / chimney




ASSEMBLING OPTIONS




Nedre luftstilkobling / Undre luftanslutning
Bottom air connection / Palamisilmaliitântä pohjassa
Unterer Luftanschluss / Raccordement d'air par le bas
Nederste lufttilkobling

I.




II.




Bakre luftstilkobling / Bakre luftanslutning
Rear air connection / Palamisilmaliitântä takana
Hinterer Luftanschluss / Raccordement d'air par l'arrière
Bageste lufttilkobling

I.



II.



III.





FIG 2

1.



2.






FIG 3



1.



2.




FIG 4




FIG 4a




FIG 5





FIG 5a






FIG 6

1.






2.



- NO** Åpne og lukk skuffene noen ganger for å justere skinnene i rett posisjon
- SE** Öppna och stäng lådorna några gånger för att kunna justera skenorna i rätt position
- GB** Open and close drawers few times to adjust the correct position of the rails
- FI** Avaa ja sulje laatikot muutaman kerran jotta kiskot asettuivat kohdilleen
- DE** Öffnen und schließen Sie die Schubladen einige Male, um die richtige Position der Schienen anzupassen.
- FR** Ouvrez et fermez les tiroirs plusieurs fois pour les ajuster correctement sur les rails
- DK** Åbn og luk skufferne et par gange for justere skinnernes korrekte position

2a.







FIG 7





Nordpeis AS, Gjellebekkstubben 11, N-3420 LIERSKOGEN, Norway
www.nordpeis.no